

COBALT

HPF-MAX



High-Power 20-Slot Frame ***Product Manual***

HPF-MAX-Frame-OM_v1.0

Cobalt Digital Inc. · 2506 Galen Drive · Champaign, Illinois 61821

Phone: 1-217-344-1243 · Fax: 1-217-344-1245 · Toll Free in the USA: 1-800-669-1691

© 2024, 2025, Cobalt Digital Inc. All Rights Reserved.

Table of Contents

Copyright	5
Disclaimer	5
Trademark Information	5
Manual Identification	5
Table 1: Record of Release, Manual Versions, and Changes	5
Contact	5
Cobalt Digital Inc. Limited Warranty	6
Important Safety Instructions	7
E334301-A6002 Compliance Statements in English and French	7
Overview	8
Product Overview	8
Warnings, Cautions, and Notes	8
Important Safety Instructions	9
E334301-A6002 Compliance Statements in English and French	9
EMC Notices	10
US FCC Part 15	10
Functional Description	11
Technical Specifications	11
Table 2: Product Specifications	11
Figure 1: Front Panel	12
Front Panel Components	12
Figure 2: Frame Interior	13
Frame Interior Components	13
Figure 3: Rear Panel Typical Components	14
Rear Panel Components	14
Table 3: Ethernet Port LEDs	14
Frame Rear I/O Modules	14
Frame Capacity For Cards and Rear I/O Modules	15
System Requirements for Network Connection to a Frame	15
DashBoard	15
Cobalt Embedded User Interface	15
SNMP Option	16
Installation and Setup	17
Important Installation Information	17
Restricted Access Area	17
Rack Mount Safety Instructions	17
Figure 4: Frame Rear Panel Connections	18
Install a Frame in a Rack	18

Open and Shut the Frame Door	19
Figure 5: Frame Door Features	19
Power a Frame	20
Figure 6: Power Supplies Inside the Frame	20
Connect the Frame to a Network	21
Set the Frame IP Address Using the Frame Controller Card	21
Figure 7: Frame Controller Card Installation	21
Figure 8: DIP Switches on the HPF-GE-FC Frame Controller Card	22
Table 4: DIP Switches Positions (HPF-GE-FC)	22
Figure 9: Frame LCD Display and Navigation Control	22
Set the Frame IP Address Using the Front Panel	23
Set the Frame IP Address Using a User Interface	23
Install a Rear I/O and Card in a Frame	24
Figure 10: Interior Features of the Frame	24
Inside the Frame	24
Install a Rear I/O Module on the Rear Panel	25
Figure 11: Rear I/O on the Rear Panel	25
Insert a Card into the Frame	26
Figure 12: Install a Card in the Frame	26
Remote Control of a Frame	26
Operating Instructions	27
Frame Control Card Operation	27
Figure 13: HPF-GE-FC Frame Control Card Controls	27
ALARM	27
SD CARD BOOT	28
SAFE BOOT	28
ALARM MUTE	28
RESET	28
DIP SWITCHES	28
IP Address Setting	28
Table 5: IP Address DIP Switches Positions	28
Password Setting	28
Figure 14: Connection Management Fields in DashBoard and COBALT Interfaces	29
Table 6: Password Protection	29
Frame Controller Card LEDs	29
Figure 15: HPF-GE-FC Frame Control Card LEDs	29
Table 7: HPF-GE-FC Controller Card LED Messaging	30
Frame Door Fan Speed	30
Update Cobalt Firmware	30
Troubleshooting	31

Table 8: Symptoms, Errors, and Corrective Action31

Available Parts **32**

Copyright

© Copyright 2024,2025, Cobalt Digital Inc. All Rights Reserved.

Duplication or distribution of this manual and any information contained within is strictly prohibited without the express written permission of Cobalt Digital Inc. This manual and any information contained within, may not be reproduced, distributed, or transmitted in any form, or by any means, for any purpose, without the express written permission of Cobalt Digital Inc. Reproduction or reverse engineering of software used in this device is prohibited.

Disclaimer

The information in this document has been carefully examined and is believed to be entirely reliable. However, no responsibility is assumed for inaccuracies. Furthermore, Cobalt Digital Inc. reserves the right to make changes to any products herein to improve readability, function, or design. Cobalt Digital Inc. does not assume any liability arising out of the application or use of any product or circuit described herein.

Trademark Information

Cobalt® is a registered trademark of Cobalt Digital Inc.

DashBoard™ is a trademark of Ross Video Limited.

openGear® is a registered trademark of Ross Video Limited.

Other product names or trademarks appearing in this manual are the property of their respective owners.

Manual Identification

Manual Name HPF-MAX-OM_v1.1 Release Date October 3, 2025

Table 1: Record of Release, Manual Versions, and Changes

Document Version	Date	Description
V1.0	September 30, 2024	Initial release. Includes UL certification information.
V1.1	October 3, 2025	Corrections and extension in instructions.

Specifications subject to change. E&OE.

Contact

Thank you for choosing this Cobalt Digital, Inc. product. The Cobalt Digital line includes video decoders and encoders, audio embedders and de-embedders, distribution amplifiers, format converters, remote control systems, and much more.

Should you have questions pertaining to the installation or operation of your Cobalt device, please contact us at support@cobaltdigital.com. Feel free to contact us about product operation, pricing, your nearest dealer, or upcoming trade shows at info@cobaltdigital.com.

Visit our website at www.cobaltdigital.com for more information.

Cobalt Digital Inc. Limited Warranty

This product is warranted to be free from defects in material and workmanship for a period of five (5) years from the date of shipment to the original purchaser, except that 4000, 5000, 6000, 8000 series power supplies, and Dolby® modules (where applicable) are warranted to be free from defects in material and workmanship for a period of one (1) year. Spotcheck units and LMNTS units will be warranted for a period of 3 years from date of shipment to the original purchaser.

Cobalt Digital Inc.'s ("Cobalt") sole obligation under this warranty shall be limited to, at its option, (i) the repair or (ii) replacement of the product, and the determination of whether a defect is covered under this limited warranty shall be made at the sole discretion of Cobalt.

This limited warranty applies only to the original end-purchaser of the product, and is not assignable or transferable therefrom. This warranty is limited to defects in material and workmanship, and shall not apply to acts of God, accidents, or negligence on behalf of the purchaser, and shall be voided upon the misuse, abuse, alteration, or modification of the product. Only Cobalt authorized factory representatives are authorized to make repairs to the product, and any unauthorized attempt to repair this product shall immediately void the warranty. Please contact Cobalt Technical Support for more information.

To facilitate the resolution of warranty related issues, Cobalt recommends registering the product by completing and returning a product registration form. In the event of a warrantable defect, the purchaser shall notify Cobalt with a description of the problem, and Cobalt shall provide the purchaser with a Return Material Authorization ("RMA"). For return, defective products should be double boxed, and sufficiently protected, in the original packaging, or equivalent, and shipped to the Cobalt Factory ServiceCenter, postage prepaid and insured for the purchase price. The purchaser should include the RMA number, description of the problem encountered, date purchased, name of dealer purchased from, and serial number with the shipment.

Cobalt Digital Inc. Factory Service Center, 2506 Galen Drive, Champaign, Illinois 61821

Office: 1-217-344-1243 · Fax: 1-217-344-1245 · Toll Free in the USA: 1-800-669-1691

www.cobaltdigital.com Email: info@cobaltdigital.com








THIS LIMITED WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON COBALT'S PART. ANY SOFTWARE PROVIDED WITH, OR FOR USE WITH, THE PRODUCT IS PROVIDED "AS IS." THE BUYER OF THE PRODUCT ACKNOWLEDGES THAT NO OTHER REPRESENTATIONS WERE MADE OR RELIED UPON WITH RESPECT TO THE QUALITY AND FUNCTION OF THE GOODS HEREIN SOLD. COBALT PRODUCTS ARE NOT AUTHORIZED FOR USE IN LIFE SUPPORT APPLICATIONS.

COBALT'S LIABILITY, WHETHER IN CONTRACT, TORT, WARRANTY, OR OTHERWISE, IS LIMITED TO THE REPAIR OR REPLACEMENT, AT ITS OPTION, OF ANY DEFECTIVE PRODUCT, AND SHALL IN NO EVENT INCLUDE SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS), EVEN IF IT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cobalt Digital Inc. 2015/Rev.1.9 Specifications subject to change. E&OE.

Important Safety Instructions


These instructions are provided to support US national and international safety compliance.

- | | |
|---|---|
| | Read these instructions. |
| | Keep these instructions. |
| | Heed all warnings. |
| | Follow all instructions. |
|  | Do not use this apparatus near water. |
| Warning | Clean only with a dry cloth. |
| | Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. |
|  | Do not defeat the safety purpose of polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet. |
| Warning | Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus. |
|  | Only use attachments/accessories specified by the manufacturer and in this manual. |
| Warning | Unplug this apparatus during lightning storms or when unused for long periods of time. |
|  | Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped. |
| Warning | |
|  | This apparatus shall not be exposed to dripping or splashing. Do not place objects such as water containers on the apparatus. |
| Warning | |
|  | The AC mains power receptacle on the rear of the apparatus shall only be connected by means of the power cord supplied with this apparatus. No other devices or cables shall be connected to this connector. If the supplied AC power cord is damaged or lost, it shall only be replaced using the AC power cord specified in this manual or by the manufacturer. |
| Warning | |
|  | To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. |
| Warning | Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type. |
| | To reduce the risk of fire, replacement fuses shall be the same type and rating as installed and as specified on the rear label adjacent to the power receptacle fuse holder. |

E334301-A6002 Compliance Statements in English and French

F.4 Restricted Access Area: Equipment is intended for installation in Restricted Access Area

Les matériels sont destinés à être installés dans des EMBLEMENTS À ACCÈS RESTREINT

L.8 Multiple power sources:   CAUTION - Shock hazard. Disconnect all power sources
ATTENTION - Danger de choc Déconnecter toutes les sources d'énergie

Overview

This manual provides installation and operation instructions for the Cobalt High-Power Frame HPF-MAX.

For more information, visit www.cobaltdigital.com. Explore guides to network control of devices, firmware updates, and other topics.

Product Overview

The Cobalt High Performance Frame (HPF-MAX) Series has a 2RU 20-slot frame. The frame provides a high density solution that offers unprecedented flexibility, ease of use, and integration. Each frame has a frame controller card supporting a single 100/1000 Ethernet port for IP-based controls. Each unit also has two pairs of BNC reference loop connectors for common timing reference among signal processes.

Warnings, Cautions, and Notes

Certain items in this manual are highlighted by special messages.

Here is some important information about product use and disposal.



Electronic device or assembly is susceptible to damage from an ESD (electrostatic discharge) event. Handle only using appropriate ESD prevention practices. If an ESD wrist strap is not available, handle device only by edges and avoid contact with any connectors or components.



Symbol (WEEE 2002/96/EC)
For product disposal, ensure the following:
Do not dispose of this product as unsorted municipal waste.
Collect this product separately.
Use collection and return systems available to you.



Warnings

Warning messages indicate a possible hazard which, if not avoided, could result in personal injury or death.



Warning

NO USER SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

Cautions

Caution messages indicate a problem or incorrect practice which, if not avoided, could result in improper operation or damage to the product.

CAUTION!

This device is intended for environmentally controlled use only in appropriate video terminal equipment operating environments.

CAUTION!

Inadequate cooling can reduce equipment reliability.
Install devices in a rack with adequate space for air circulation, especially devices with no fans for cooling.

Notes








Notes provide supplemental information to the accompanying text. Notes typically precede the text to which they apply.



Important notes regarding product use are shown.
Failure to observe may result in unexpected or incorrect operation.

Important Safety Instructions



These instructions are provided to support US national and international safety compliance.

- Read these instructions.
 - Keep these instructions.
 - Heed all warnings.
 - Follow all instructions.
-  **Warning** Do not use this apparatus near water.
- Warning** Clean only with a dry cloth.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
-  **Warning** Do not defeat the safety purpose of polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
-  **Warning** Only use attachments/accessories specified by the manufacturer and in this manual.
- Warning** Unplug this apparatus during lightning storms or when unused for long periods of time.
-  **Warning** Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
-  **Warning** This apparatus shall not be exposed to dripping or splashing. Do not place objects such as water containers on the apparatus.
-  **Warning** The AC mains power receptacle on the rear of the apparatus shall only be connected by means of the power cord supplied with this apparatus. No other devices or cables shall be connected to this connector. If the supplied AC power cord is damaged or lost, it shall only be replaced using the AC power cord specified in this manual or by the manufacturer.
-  **Warning** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
- Warning** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- Warning** To reduce the risk of fire, replacement fuses shall be the same type and rating as installed and as specified on the rear label adjacent to the power receptacle fuse holder.

E334301-A6002 Compliance Statements in English and French

F.4 Restricted Access Area: Equipment is intended for installation in Restricted Access Area

Les matériels sont destinés à être installés dans des EMBLEMES À ACCÈS RESTREINT

L.8 Multiple power sources:   CAUTION - Shock hazard. Disconnect all power sources
ATTENTION - Danger de choc Déconnecter toutes les sources d'énergie

EMC Notices

US FCC Part 15

This equipment has been tested and found to comply with the limits for a class A Digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case users will be required to correct the interference at their own expense.



Changes or modifications to this equipment not expressly approved by Cobalt Digital Inc. could void the user's authority to operate this equipment.

CANADA

This Class "A" digital apparatus complies with Canadian ICES-003.

EUROPE

This equipment is in compliance with the essential requirements and other relevant provisions of CE Directive 93/68/EEC.

INTERNATIONAL

This equipment has been tested to CISPR 22:1997 along with amendments A1:2000 and A2:2002 and found to comply with the limits for a Class A Digital device.

Functional Description

The HPF-MAX is an openGear-compatible 2RU high-density modular frame offering 600 Watts of net (user) available power in a high-capacity 20-slot format. Capacity varies with card and Rear I/O module choice.

High power-density power supplies (single standard, redundant second optional) and engineered cooling/ventilation design allow 10 high-power cards in a frame (10 x 60W = 600 W), or 20 medium-power cards in a frame (20 x 30 W = 600W). Separate forced-air cooling paths are provided for the card area and the power supply areas. An intelligent fan controller adjusts fan speed with changes in power supply loading and temperature.

The HPF-MAX can accommodate two front-loaded PS-MAX power supply modules. Adding a second (optional) supply gives the frame full power redundancy. The PS-MAX power supply unit is interchangeable as a primary or redundant power supply module, with supplies in either position being hot-swappable. Each power supply has an independent cooling fan and a front-mounted power switch.


The HPF-GE-FC Network Controller Card (furnished as standard on the HPF-MAX frame) allows Gigabit Ethernet connectivity to any number of connections for full multi-point control and monitoring via free DashBoard software.

The frame is equipped with two independent reference buses that can supply a selected reference to cards within the frame.

Technical Specifications

Table 2: Product Specifications

Item	Characteristic
Part number, nomenclature	HPF-MAX High-Power 20-Slot Frame (PN HPF-MAX-CN) Includes (1) PS-MAX Power Supply Module, (1) Power cord, and (1) HPF-GE-FC Network Controller Card.
Installation / usage environment	Intended for installation and usage in a restricted access environmentally controlled installation using openGear-compliant cards and network control.
AC Line Input (per each of 2 (max) PSU IEC inputs)	100-240 VAC, 48-63 Hz, 600 Watts maximum
Environmental: Operating temperature and Relative humidity (operating or storage)	+32 °F – +104 °F (0 °C – +40 °C) < 95%, non-condensing
Available user (net) power	600 Watts continuous-operation maximum
Available user card slots	20 maximum
Frame communication	100/1000 Mbps Ethernet with Auto-MDIX
Physical: Dimensions (WxHxD): Weight (with standard power supply PS1):	19" x 3.5" (2RU) x 17" (48 cm x 9 cm x 43 cm) (Dimensions include component projections such as mounting tabs, etc.) 14.0 lb. (6.4 kg) (with single standard power supply PS-MAX and HPF-GE-FC Network Controller Card)
Reference Video Input	Number of Inputs: Two non-terminating (looping) Frame Reference inputs, Signal Level: 1 Vp-p nominal Signal Type: Analog video sync (black burst or tri-level) Impedance: 75 Ohms , Return Loss: > 30 dB to 30 MHz Allowable Maximum DC on Ref Input: ±1.0 V
Optional accessories	PS-MAX – Extra (redundant) frame power supply and power cord HPF-GE-FC Advanced Network Controller Card provides gigabit switch connections to all frame slots 9000-FSB-Lor 9000-FSB-S Frame support bracket kit

Figure 1: Front Panel

Front Panel Components

The front panel of each frame has controls and indicators:

CAUTION! Opening the door removes power from the fans, stopping ventilation of the frame.
Open the door only briefly while inserting, removing, or servicing cards in the frame.

DOOR WITH FANS: (Figure 1, Item A) The door has a screen over five fans to ventilate the frame. The fans pull in air at the front and push air out at the back and top of the frame. When the door is open, the fans are disconnected from power.

CAUTION! The LCD screen on the frame is not a touch screen.
Any pressure on the screen may damage the screen beyond repair, requiring replacement.


LCD SCREEN: (Figure 1, Item B) On the right side of the front panel a small LCD screen displays information. Moving the nearby navigation control actuates four screens with IP address information and frame temperature.

NAVIGATION CONTROL: (Figure 1, Item C) Near the LCD screen is a small gray toggle. It can be moved and pushed in to show or modify information on the LCD screen.

LATCH: (Figure 1, Item D) On the right and left sides of the front panel, small handles can be moved toward the center of the panel to free latches and allow opening the front door of the frame.

EAR BRACKET: (Figure 1, Item E) Slots in the ear brackets on each side of the frame enable securing the frame in a 19-inch EIA-310 rack.

Figure 2: Frame Interior



Frame Interior Components

Inside the frame there are several components:

POWER SUPPLY: (Figure 2, Item A) On the right (PS2) and left (PS1) in the frame there is a compartment for a power supply. An LED, power switch, toggle, and handle is visible on each installed power supply. One power supply is required to operate the frame. An optional second power supply may be installed for redundant power.


FRAME CONTROLLER CARD: (Figure 2, Item B) On the right side of the frame is the frame controller card. The card is secured in the frame with a small screw in the card mount. The HPF-GE-FC Network Controller Card provides gigabit communication with installed cards to enable firmware updates.

CARD SLOTS: (Figure 2, Item C) 20 upper and lower slotted plastic plates allow cards to be aligned and inserted into frame network receivers and Rear I/O Modules.

FRAME CARD CONNECTORS: (Figure 2, Item D) 20 card receivers delivering frame power and communication connection are mounted at the rear end of the lower slots.

NUMBER GUIDE: (Figure 2, Item E) In front of the lower card slots is a label showing a number for each slot. Slots are numbered from left to right, 1 to 20.

Figure 3: Rear Panel Typical Components



Rear Panel Components

The rear panel of each frame has connectors and covers:

ETHERNET PORT: The upper RJ45 Ethernet connector (Figure 3, Item A) allows connection of the frame to a 100/1000 Ethernet LAN using Cat 5 (or better) cable to access the frame's controls through an Internet browser. The lower RJ45 port is reserved for future use (Figure 3, Item B).

Table 3: Ethernet Port LEDs

Position and Color	State	Description
Right LED, Amber	OFF ON	No Link Established Link Established
Left LED, Green	OFF ON	No Network Activity Blinking LED shows network activity

POWER SOCKETS: (Figure 3, Item C) On the left and right sides of the rear panel of the frame are grounded power sockets, supporting one or two (optional and redundant) power supplies. At least one power supply must be installed in the frame and connected through a cable to main power. Retainer clips help hold a cord plug on the frame. LEDs on the power supplies inside the frame show when the supply is powered ON.

BNC REF LOOPS: (Figure 3, Item D) The two pairs of upper and lower REF LOOP BNC connectors on the right side of the frame's rear panel. These are marked REF1 LOOP or REF2 LOOP. These connectors allow input or daisy chain connection of a timing reference source.

REAR I/O MODULE SLOTS AND COVERS: (Figure 3, Item E) The rear panel of the frame has ten Rear I/O module tab slots in a lower plate. There are ten threaded holes for rear module retainer screws in the upper plate. Ten metal covers with screws and elastomer washers protect empty slots from intrusion.

Frame Rear I/O Modules

Select cards then Rear I/O modules to meet your input and output requirements. All signal inputs and outputs enter and exit a card through the card edge backplane connector. A Rear I/O module breaks out the card edge connections to industry standard connectors to interface with other components and systems in the signal chain.

Frame Capacity For Cards and Rear I/O Modules



Various Rear I/O modules for Cobalt cards are available and are described in respective product information for the cards.

A frame's card capacity is determined by the Rear I/O modules used. A 20-slot frame can be fitted with a mix of rear module types, offering a variety of connector options while maximizing frame capacity.

The frame has a 600 watt power limit, which may not allow installation of 20 high-power cards in the frame. Select cards then Rear I/O modules to meet your input and output requirements. Signal inputs and outputs enter and exit a card through the card edge backplane connector. A Rear I/O module breaks out the card edge connections to industry standard connectors to interface with other components and systems in the signal chain.

A split rear module takes one rear module slot and connects to two cards in the frame. Not all openGear cards are supported by split rear modules. A rear module may not support all connections offered by a card.

The standard width rear module takes one module slot and connects to only one card in the frame, leaving one card slot empty, not available to hold a card.

Some rear modules take two or more module slots, while connecting to only one card, making several slots unavailable for other cards and rear modules. Some cards take more than one card slot due to space required by attached daughter cards.

System Requirements for Network Connection to a Frame

The frame interface requires a network capable computer, a current browser, and a network connection to the frame. Frame network interfaces are available, such as Ross DashBoard software, an interface embedded in the frame controller card, or the SNMP (Simple Network Management Protocol) software option for the controller card.



All user control interfaces described here are cross-compatible and can operate together as desired. Where applicable, a control setting change made using a particular user interface is reflected on another connected interface.

DashBoard

DashBoard User Interface – Using DashBoard, cards in the HPF-MAX Frame can be controlled from a computer and monitor.

DashBoard allows users to view all frames on a network with control and monitoring for all populated slots inside a frame. This simplifies the setup and use of numerous modules in a large installation and offers the ability to centralize monitoring. Cards define their controllable parameters to DashBoard, so the control interface is always up to date.

The DashBoard software can be downloaded from the openGear website:
<https://www.opengear.tv/frame-and-control/control-system/download-dashboard/>.

Cobalt Embedded User Interface

The frame can also be accessed with a web browser through an embedded user interface on the frame controller card, using the IP Address of the frame.

SNMP Option

A network card with the SNMP option provides a standardized framework for monitoring and managing network devices. The SNMP option supports the SNMP v1|v2, and requires an SNMP manager software on a network connected to the frame. SNMP can be used in parallel with the DashBoard and the Cobalt frame controller user interfaces. The SNMP option supports the SNMP v1|v2, and requires an SNMP manager software on a network connected to the frame. SNMP is a software option that may be purchased before or after frame delivery. SNMP software may be applied to the controller card in the field. Product name SNMP-HPF-FC provides SNMP (v1 and v2) control and monitoring for the HPF-GE-FC Network Controller Card.

Installation and Setup

**Warning**

NO USER SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



Electronic device or assembly is susceptible to damage from an ESD (electrostatic discharge) event. Handle only using appropriate ESD prevention practices. If an ESD wrist strap is not available, handle device only by edges and avoid contact with any connectors or components.

CAUTION!

While handling the frame, do not press on the LCD panel on the front of the frame. This LCD panel is not a touch screen and may be damaged by finger pressure on it.

Important Installation Information

Before beginning installation, refer to the following information.

Restricted Access Area

Equipment is intended for installation in a Restricted Access Area.

Les matériels sont destinés à être installés dans des EMPLACEMENTS À ACCÈS RESTREINT.

Rack Mount Safety Instructions

The following or similar rack-mount instructions are included with the installation instructions:

A) Elevated Operating Ambient - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T_{ma}) specified by the manufacturer.


B) Reduced Air Flow - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised.

C) Mechanical Loading - Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.

D) Circuit Overloading - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring.

Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

E) Reliable Earthing - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips)."

Figure 4: Frame Rear Panel Connections

Install a Frame in a Rack

1. Contact Cobalt support if parts are missing. Remove the frame from packaging.
2. For normal installations, the frame is designed to be supported in a standard EIA-310 19-inch rack by securing the frame by its four front panel mounting holes only, without added rear support.
If a frame is installed in a truck or equipment case (fly pack), frame support rails (9000-FSB-S or 9000-FSB-L) are recommended for the frame in a rack.
3. On the front panel of the frame, first install right and left screws in the lower holes in the ear brackets (Figure 1, Items A) to hold the frame on the rack. This makes placement and alignment easier for upper screws put through the ear bracket holes into the rack.
4. On the frame's rear panel, connect an Ethernet cable (Cat 5 or better) to the upper RJ45 port (Figure 4, Item B) on the left side of the frame. The lower RJ45 port is reserved for future use.
5. The power socket on each side of the frame is connected only to the power supply inside. There is no cross connection between sockets to power supplies. Connect a cable to one or both of the frame's power supply sockets (Figure 4, Items C). Where two power supplies are installed in the frame, use of both sockets provides redundant power to the frame.
6. Connect a cable from a compatible analog timing source to one of the two REF LOOP BNC connectors (Figure 4, Items D) on the rear panel of the frame (REF1 LOOP or REF2 LOOP).


General practice is input on the left and loop out on the right, although looping reference connectors can receive reference input on either connector of the looping pair.

If the open BNC connector is not connected to another device, terminate the connector with a 75 Ohm dummy load.

If no timing source is connected to the frame, there is no need to terminate either REF LOOP connectors.

Open and Shut the Frame Door

Figure 5: Frame Door Features



1. On the front of the frame, push in the left and right latch handles (Figure 5, Items A) toward the center of the door front and open the door.
2. Pull the door out on its slotted retainers (Figure 5, Items B) and let the door lay open. Do not put more weight on the door or the retainers may be deformed, making door shutting more difficult.

When necessary, the door may be removed or replaced.

Pull the door out on the retainer until the round hole near the end of the slot is around the fastener (Figure 5, Items C) in the frame.

Depress a section of the retainer to free the retainer from the fastener.

Fan operation is required for ventilation of the frame, so removing the door and powering ON the frame results in a persistent alarm.

The alarm may be silenced using the controller card alarm switch or a user interface alarm settings.


3. Look inside the door at the card receiver (Figure 5, Item D) to make sure it is clean and free of defects. The receiver connects to the frame controller card (Figure 5, Item E) when the door is fully closed.
4. Lift and push the frame door back onto the frame until both door latches secure the door on the frame, connecting power to the front LCD and the door fans.

The fans go to higher speed immediately after the door is shut, but will settle down to the speed set by the controller card and user interface fan speed setting.

If the LCD screen does not show information correctly, open and shut the door to restore correct connection between the card receiver and the frame controller card.

Power a Frame

Figure 6: Power Supplies Inside the Frame




1. If there are cables connected to the rear power sockets on the frame, power ON the frame by pressing the rocker switch (Figure 6, Item D) to the I (ON) position.
2. Power supplies may be hot swapped. Make sure the other power supply is powered ON before powering OFF the supply being removed or replaced.
3. Grip the handle (Figure 6, Item C) over the power supply fan, hold the latch accuator (Figure 6, Item E) away from the outer wall of the frame, and pull the supply out of the frame. The latch will resist power supply movement unless it is held fully away from the frame outer wall.
4. Insert a power supply into the frame compartment with the latch near the outer wall of the frame. Hold the latch accuator away from the frame wall to prevent excess wear to the latch until the power supply is fully connected to the frame.
5. Power ON the newly inserted power supply to provide redundant power supply to the frame. The LED light (Figure 6, Item F) on the power supply will illuminate.

Connect the Frame to a Network

The IP Address for the frame may be set by use of the frame controller card DIP switches, the front panel LCD display and toggle control, or a user interface connected through a network to the frame. The DIP switches positions on the frame controller card enable IP Address change from the front panel or through a user interface.


Set the Frame IP Address Using the Frame Controller Card

Figure 7: Frame Controller Card Installation



1. For easier access to the frame controller card, remove nearby cards (if previously installed) from the frame before handling the controller card.
2. In the frame controller card housing, loosen the #1 Phillips screw (Figure 7, Item B) that goes in a hole in the frame controller card.
3. Due to tight mechanical tolerances, removing and installing the card in the frame card receiver may be difficult.
4. On the network controller card (HPF-GE-FC), IP Address options can be set with DIP switches 1 and 2 (Figure 8) positions according to a table printed on the card (shown in Table 4).

Figure 8: DIP Switches on the HPF-GE-FC Frame Controller Card




HPF-GE-FC
DIP Switches 1 and 2 for Frame IP Address

Table 4: DIP Switches Positions (HPF-GE-FC)

DIP Switch 1	DIP Switch 2	0: OFF, 1:ON
0	0	User
0	1	DHCP
1	0	192.168.2.1
1	1	10.1.2.1

5. Some pressure on the both the upper (Figure 7, Item C) and lower (Figure 7, Item D) parts of the card end may be required to insert the card into the frame card receiver.
6. Tighten the card housing screw (Figure 7, Item B) through the card to secure the card in the frame.
7. Power ON the frame and connect it to a network using a Cat 5 (or better) Ethernet cable through the RJ45 connector on the rear panel of the frame.

Figure 9: Frame LCD Display and Navigation Control



Set the Frame IP Address Using the Front Panel

1. No information shows on the LCD until the frame is powered on using a power supply switch inside the frame.

When the frame is powered on, "HPF-MAX" (or a name assigned by other means) and an IP address (IPv4 standard) shows on the LCD display (Figure 9, Item B), either setup previously or forced by DIP switch positions on the frame controller card.

2. Move the navigation control (Figure 9, Item B) to the right four times and the display cycles through the following menus: "Slot 0 Temperatures", "Current Network Settings", "Static Network Settings", then back to the default menu of "HPF-9500" and an IP address. Move the navigation control four times right, left, up, or down and the screen will show these menus.

The Slot 0 Temperatures are for sections of the frame: F (front), M (middle), and R (rear). The navigation control does not control frame temperature.

3. Move the navigation control to the left once to display the "Static Network Settings" menu.
4. At the center position, push in and hold the navigation control to enter the "Static Network Settings" edit menu.

If the frame controller card DIP switches 1 and 2 are set to anything other than USER, editing of the IP address cannot be done with the navigation control. A warning message shows on the screen "Override by Switch (sw1/sw2) Enabled". In DashBoard or a Cobalt user interface, the IP Address may be changed. The address change will not be applied by the controller card until the card DIP switches are set to USER.

5. On the editing screen (Figure 9, Item C), move the navigation control to the left or right to move the cursor among IP Address settings for IP, Mask, and Gateway number options.
6. In each number position move the control up to increase the value or down to decrease the value.
7. Select DHCP or STATIC by moving the cursor over the left side radio button circle, and pressing in on the control.
8. Move the cursor to Save to apply changes or Back to deny the changes.
9. Press in on the control to apply the choice. The screen will show the result of the choices made in the edit screen.

Set the Frame IP Address Using a User Interface

The frame may be accessed by a computer connected to the same network as the frame. The frame IP address can be changed either through Ross DashBoard or by typing the IP address for the frame into a web browser (an embedded Cobalt user interface will show, providing control of the individual frame).

1. Open a web browser on a computer connected to the same network as the frame. Based on the setting of the DIP switches in the frame controller card in the frame, or connect to the Forced IP address also shown on the frame LCD screen. The address may vary based on previous operation of the frame. Specifications are subject to change.
2. In the IP Settings window select either Static or DHCP, depending on your local network needs.
3. For the Static option, enter the information needed to connect the frame to your local network. For the DHCP (Dynamic Host Configuration Protocol) option, automatic communication will establish a connection if your local network supports a DHCP server.

If the DIP switches configuration is set to any of the "forced" IP address modes, a warning message may show in software connected to the frame. To avoid the warning message and apply the network settings, set the DIP switches to the User (software) mode and reboot the frame. Upon reboot, the frame will use the network settings set in software.

Install a Rear I/O and Card in a Frame

Inside the frame, slots and card receivers must be clean and free of obstruction to allow installation of Rear I/O modules on the rear panel of the frame and cards inside the frame.

CAUTION!

Make sure cards and Rear I/O modules are not damaged before installation, due to tight mechanical tolerances in connections. If card connectors are damaged, do not install the card in a frame. If Rear I/O card receiver connectors are damaged, do not install the Rear I/O in a frame. Contact Cobalt support if damage is found.

CAUTION!

Always ground yourself before handling cards or Rear I/O modules. Prevent ESD (electrostatic discharge into circuits) by holding a device by the long edges without touching components or exposed metal.




The fans on the frame door do not operate unless fully connected to frame power.

An alarm may sound if the door is not completely latched.

With some cards, continuous ventilation is required to prevent overheating.

Do not leave the door open when operating high-demand processes, such as decoders, encoders, or cards processing 4K signals.

Figure 10: Interior Features of the Frame




Inside the Frame

1. On the front of the frame, push in the left and right latch handles (Figure 10, Items A) toward the center of the door front and open the door.
2. Pull the door out on its slotted retainers and let the door lay open on its hinge.

3. Look into the frame to make sure card receivers (Figure 10, Items C) and slots (Figure 10, Items B) are clean and free of defects. Make sure components of any previously installed Rear I/O or card does not block frame slots.
4. Refer to the slot guide (Figure 10, Item D) inside the frame door for the numbers marked on the slots. Choose card slots appropriate for the card to go into the frame.
5. After installation of a card or cards, lift and push the frame door back onto the frame until both door latches secure the door on the frame, connecting power to the front LCD and the door fans.

Install a Rear I/O Module on the Rear Panel

Figure 11: Rear I/O on the Rear Panel



A card with an attached daughter card or cooling devices takes several frame slots. These double-wide cards must be installed in an odd-numbered (1, 3, 5, etc.) frame slot to allow space for other cards in the frame.

1. Where installed, loosen the retainer Phillips head screw (Figure 11, Item A) in a cover plate (Figure 11, Item B) on the back of the frame.
2. Remove and retain the cover plate from the frame.



Some modules with SFP (Small Form-factor Pluggable) fiber module ports may be difficult to install in the frame. To allow clearance, move the capturing washer (Figure 11, Item D) out on the screw (Figure 11, Item A) before installing a module.

3. With the BNC or other cable connectors of the module facing out from the frame, insert the lower key tab of the Rear I/O module (Figure 11, Item C) in a lower slot on the frame.




Do NOT force a Rear I/O screw into the frame if there is resistance. Cross threading a screw in the hole may cause the frame to be damaged beyond repair. Remove the screw and restart it in the frame.

4. Tighten the captive Phillips head screw (Figure 11, Item A) at the top edge of the module into the threaded hole in the frame.

Insert a Card into the Frame

Figure 12: Install a Card in the Frame



1. Where the Rear I/O is installed, insert the card (Figure 12, Item A) into the chosen upper and lower slots in the frame.
2. Press the card in the frame slot to connect the card to the frame and Rear I/O card receivers. Tight machine tolerances are sustained to provide a reliable electrical connection, so fully seating the card in the frame and Rear I/O card receivers may be difficult.
3. Lift and push the frame door back onto the frame until both door latches secure the door.
4. Use a user interface to make sure the card communicates with the frame and local network.
5. When needed, pull down the top edge of the white ejector tab (Figure 12, Item B) to pull the card from the Rear I/O module.



If there is NOT communication and control of a card, remove the card from the frame. Examine the card edge and the card receiver in the frame for possible damage. Replace the card in the frame and make sure the card is fully seated in the frame. If there is NOT communication, insert the card in another slot, or into another frame. Contact Cobalt support if damage is found.

Remote Control of a Frame

The frame may be accessed, monitored, and operated by remote control using a computer connected to the same network as the frame. There are options for remote control of the frame, such as DashBoard, an embedded Cobalt user interface in the frame controller card, or an SNMP software option. Features vary among frames and interfaces.

Operating Instructions


Frame Control Card Operation

The controls on the frame control cards (HPF-GE-FC) are rarely needed.



Do not press buttons or change DIP switches positions elsewhere on the card.
The other buttons and DIP switches support only manufacturing and quality control in card production.

Figure 13: HPF-GE-FC Frame Control Card Controls



ALARM

This switch (Figure 13, Item A) enables or disables the card in sounding an alarm condition.

An alarm sounds from the frame controller card when there is a fault in frame operation and the ALARM switch is in the ENABLE position.

No alarm will sound from the card when the switch is in the DISABLE position.

Press the MUTE button on the controller card to stop an alarm for 120 seconds.

Standard alarm conditions are the open frame door, fan failure, and power supply failure.

Alarm conditions may be set in a user interface.

These conditions may cause an alarm:

Open frame door: The sensor enables the alarm, if the door connection is not complete, The door needs to be fully connected to operate ventilation of the frame. Some cards need full ventilation when they operate due to high-demand processors. Open and shut the door to make sure the connection is secure.

Fan failure: Make sure which fan is not rotating. Clear debris and dust from all fans. Shut the door.

If this does not restore fan operation and silence the alarm, disable the alarm temporarily.

Replace the individual fan or the whole door.

Power supply failure: Make sure the LED on the power supply is powered ON and that the power supply fan is operating. If the LED and fan do not operate, swap power supplies.

If an alarm condition persists, contact Cobalt support.

SD CARD BOOT

This button is rarely used. The SD CARD BOOT button (Figure 13, Item B) supports factory installation of the operating system for the frame control card. The button must be held down while the SD card is inserted into the card holder. An SD card is not available for field operation of a frame.

SAFE BOOT

This button is rarely used. The SAFE BOOT button (Figure 13, Item C) supports loading a firmware image previously saved in the controller card memory. If the button is held down while the frame is powered ON, the card will load a saved factory image. This is a safety feature to recover from loading faulty firmware.

ALARM MUTE

The ALARM MUTE button (Figure 13, Item D) silences the card from sounding an alarm for 120 seconds during an alarm condition. Muting the alarm may allow time for the alarm condition to be corrected.

RESET

This button is rarely used. The RESET button (Figure 13, Item E) reboots the frame, reloading the operating system for the control card.

DIP SWITCHES

The DIP switches near the front edge of the frame controller card (Figure 13, Item F) forces an IP Address for the card and frame or sets a password limitation on the card. A small graphic on each card describes options for DIP switch positions.

IP Address Setting

Once the frame is installed and setup, rarely do these DIP switches need to be changed. Select either the DHCP or User option using DIP switches 1 and 2. Make sure of your local network policy for addresses before changing these DIP switches. The DHCP setting is usually used for automatic, rapid connection to a large network when the network is supported by a DHCP server.

Table 5: IP Address DIP Switches Positions

DIP Switch 1	DIP Switch 2	0: OFF, 1:ON
0	0	User
0	1	DHCP
1	0	192.168.2.1
1	1	10.1.2.1

Password Setting

The standard approach is to put DIP Switch 3 in the (1) ON position for no password.

The password option is rarely used but is available for security purposes. In a user interface (DashBoard or COBALT), under the Network Tab, three fields show under Connection Management for Password settings. The Master Password has no effect unless a character string is entered in place of the placeholder (eight

asterisks) character string. In either DIP Switch position, this section is visible in a controller card user interface.

Figure 14: Connection Management Fields in DashBoard and COBALT Interfaces




Table 6: Password Protection

DIP Switch 3	0: OFF, 1:ON
0	User Password
1	None (no password)



Currently, DIP switch 4 is not used. It does not control a card function.

Frame Controller Card LEDs

LEDs illuminate on the frame controller card during operation. Sometimes the LEDs are visible through the ventilation holes in the front of the frame.

Figure 15: HPF-GE-FC Frame Control Card LEDs




Table 7: HPF-GE-FC Controller Card LED Messaging

LED position	Labels	Color	Message
A (top, above SD Card input)	OVER TEMP	Red	Frame is near over temperature shutdown.
B	PWR	Green	Power is supplied to the card.
C	OK	Green	When lit, controller card has no detected errors and is receiving power properly.
D	ERR	Red	When lit, indicates an alarm condition is occurring on a card within the frame.
E	MCU	Blue	Main controller unit (MCU) status indicator normal status is blinking.
F (bottom)	CAN	Blue	CAN bus activity indicator. When lit, the controller card is transmitting messages on the internal communications bus.

Frame Door Fan Speed

After the frame door is opened and shut, the fans accelerate momentarily to cool interior electronics, then the speed settles down to the speed set in the frame controller card. Refer to frame fan control options in remote control software. For example, DashBoard offers two frame fan speed settings, Auto or Max.

Update Cobalt Firmware

On occasion, a firmware release is made to add features or to apply improvements. Firmware may be downloaded from the web and loaded into a connected frame.

1. View the installed firmware version for a frame and installed cards using the DashBoard interface connected to the frame.
2. Current Cobalt firmware is available on the Cobalt website. In a web browser, go to <https://www.cobaltdigital.com/support/firmware>
3. Search the list for the current firmware for the Cobalt product.
4. Click on the firmware link for the product.
5. In a dialog window, select a location to save the file, and click OK.
6. Upload the file to the connected Cobalt product using the DashBoard interface.
7. Reboot the Cobalt product to apply a firmware update.

Troubleshooting

The table below provides frame and remote control troubleshooting information. If cards in the frame or remote connections exhibit listed symptoms here are some possible solutions. If an alert message shows on the remote control interface, it may be disabled using an interface drop-down menu.

Table 8: Symptoms, Errors, and Corrective Action

Symptom	Error	Corrective Action
Remote control interface does not show or control a frame or card in a frame	Communication	Make sure cables are connected Make sure frame IP Address is correct Make sure DHCP server is operating if DHCP chosen Reboot the frame Use an alternate control interface to see the frame Move card to another card slot without a Rear I/O Move card to another frame
Intermittent frame or card failure	Damage	Make sure frame and card external connections are secure Make sure frame control card and power supplies are fully seated in the frame Make sure card is fully seated in the Rear I/O Replace damaged parts (contact Cobalt support)
Signals input to a frame or card do not result in expected output	Communication	Make sure cards and frame power supply are fully seated Make sure frame and card connections are secure Make sure Rear I/O connections are correct and secure
Audible alarm	Door is open, fan failure, or power supply failure	Clean fan or replace faulty door, fan, or power supply (contact Cobalt support)
LCD screen shows odd images	Connection	Open and shut the frame door to improve connection between the controller card and the LCD screen
LCD screen failure	Damage	Any pressure on the screen may damage the screen beyond repair, requiring replacement (contact Cobalt support)
HPF-GE-FC controller card fan noise	Damage	Excessive noise may show impending fan failure, Replace frame controller card

If these or other issues arise in the installation, setup, or operation of this device:

Generate a system log file with remote control interface to capture system data

Send an email to support@cobaltdigital.com, call 1-217-344-1243, or call Toll Free in the USA 1-800-669-1691.

Available Parts

HPF-GE-FC Network Controller Card

This advanced network controller card provides gigabit switch connections to all frame slots in the frame.

HPF-GES-FC Network Controller Card with SNMP

This advanced network controller card provides gigabit switch connections to all frame slots in the frame. The network controller card has SNMP (Simple Network Management Protocol) providing a standardized framework for monitoring and managing network devices. The SNMP option supports the SNMP v1|v2, and requires an SNMP manager software on a network connected to the frame. SNMP is a software option that may be purchased before or after frame delivery. SNMP software may be applied to the controller card in the field. Product name HPF-GES-FC provides SNMP (v1 and v2) control and monitoring for the Network Controller Card.

PS-MAX Power Supply

This 720 watt power supply has a power cord suitable for the installation region. This power supply may only be used in the Cobalt HPF-MAX frame.

9000-FSB-S Frame Support Bracket Kit

These 16.5 inch rails support 1RU rear rack mounting for a Cobalt HPF-9000, HPF-9500, or HPF-MAX 20-Slot Frame. The short (9000-FSB-S) option is for racks that are 18—26 inches deep.

9000-FSB-L Frame Support Bracket Kit

These 21.5 inch rails support 1RU rear rack mounting for a Cobalt HPF-9000, HPF-9500, or HPF-MAX 20-Slot Frame. The long (9000-FSB-L) option is for racks that are 26—32 inches deep.

Large Fan HPF-MAX Door

On the HPF-MAX door, all five fans are large, and single fans are available.

HPF-MAX-Front-Door-Panel

Frame door including five large fans.

This page is intentionally left blank.



HPF-MAX-Frame-OM_v1.0

Cobalt Digital Inc. · 2506 Galen Drive · Champaign, Illinois 61821

Phone: 1-217-344-1243 · Fax: 1-217-344-1245 · Toll Free in the USA: 1-800-669-1691

© 2024, 2025 Cobalt Digital Inc.

Specifications subject to change. E&OE. · Printed in the USA.