


9902-UDX Block Diagram

*Multi-Input Up-Down-Cross Converter/Framesync
with Auto-Changeover and Character Burn*



* SDI I/O and bypass are a function of rear I/O module. Refer to rear I/O modules descriptions for more information.
SDI output RLY BYP B outputs copy of SDI Out 1 crosspoint selection in normal operation. In power loss failover, RLY BYP B passive outputs SDI In B.

COBALT Cobalt Digital Inc.
2506 Galen Drive
Champaign IL, 61821

217.344.1243
info@cobaltdigital.com
www.cobaltdigital.com