

## ARIA OG-AUD2-DANTE ARIA OG-AUD4-DANTE

You can update your card by downloading the new Update software by going to the Support>Firmware link at [www.cobaltdigital.com](http://www.cobaltdigital.com).

Download “Firmware Update Guide”, which provides simple instructions for downloading the latest firmware for your card onto your computer, and then downloading it to your card through DashBoard™.

Software updates are field-installed without any need to remove the card from its frame.

The table below lists released software versions and describes the corresponding functions additions, improvements, or corrections.

Firmware Version	Description
ARIA OG-AUD2/AUD4-DANTE Firmware Release v1.0.3	<b>Bug Fix</b> <ul style="list-style-type: none"><li>Corrected a condition that would sometimes result in no SDI input lock when a signal was present.</li></ul>
ARIA OG-AUD2/AUD4-DANTE Firmware Release v1.0.2	<b>Bug Fix</b> <ul style="list-style-type: none"><li>Corrected an issue where a user could inadvertently route AES inputs to other audio outputs.</li><li>When bi-directional AES audio groups are switched from input to output, the device now updates the audio bus route selections to remove the AES inputs preventing users from accidentally routing them.</li></ul>
ARIA OG-AUD2/AUD4-DANTE Firmware Release v1.0.1	<b>Bug Fix</b> <ul style="list-style-type: none"><li>Corrected an issue that prevented users from routing MADI/Dante audio signals to the downmixer and/or the flexmixer.</li></ul>