Cobalt Digital Inc. • 2506 Galen Drive • Champaign IL 61821 USA • (217) 344-1243 • www.cobaltdigital.com • support@cobaltdigital.com

The release notes contain information on how to update your WAVE router with the latest firmware. This document also provides information on features released and bugs fixed for each version.

To update your WAVE 64x64, WAVE 32x32, or WAVE 36x36 router, download the latest software by accessing the **Support>Firmware** link at www.cobaltdigital.com. Look for the update for the WAVE 64x64/WAVE 32x32 router. Open a browser pointing it to the previously installed WAVE 64x64 or WAVE 32x32 router on your network and select the **Settings** menu in the WAVE router GUI.

NOTE: If you have multiple WAVE routers on your network, make sure you are connecting to the router hardware that you intend to update the firmware. For that information check out the **About** section (in Settings) and look for the **Serial Number** of the unit you intend to update. The address bar of your browser is also an area to look at to confirm the correct device is being updated.

Router Table	Salvos	≔ Status	notocols	Contraction Settings	<u>COBALT</u>	
		About				
		Product				WAVE RTR-64x64 SDI router
		Company				Cobalt Digital, Inc
		Software Revision	(Platform)			1.4.0-release-b47b007a
		Software Revision	(Neo)			1.5.0-main-a3b77db0
		Hardware Revision	n			с
		Serial Number				534551

Figure1. About Section

As shown in Figure 1, select **Settings**, scroll down and select **About**. Confirm you see the WAVE Router you intend to update. Select the **Administration** drop-down menu bar. Under **File Upload**, select **File** and find the *downloaded file* on your computer. Once the correct file is found, select it and choose **Upload**. The system will install the new firmware.

Router Table	Salvos		🚓 Protocols	Settings	COBALT
		About			
		IP Settings			
		Administration			
		File Uplo This is the place to Update File Choose File Select an update pa Upload	to upload various fil No file chosen	ies to the system inclu	ding firmware updates and licenses. Please select a file and click on the upload button.


Figure 2. File Upload

When complete, the WAVE router control system will automatically reboot the internal controller. **NOTE:** There will be an interruption of routing services during the update and reboot of the controller.

Cobalt Digital Inc. • 2506 Galen Drive • Champaign IL 61821 USA • (217) 344-1243 • www.cobaltdigital.com • support@cobaltdigital.com

The following table lists released firmware versions and describes the corresponding functions and additions, improvements and/or corrections.

Firmware Version	Description
Wave Router Series Firmware	Added Features
Release v1.8.0 11/21/2024 - Present	• Added support for the WAVE 36 x 36 Router.
	Bug Fixes
	• Resolved an issue that may result in salvos not being added when attempting to create a new salvo either from the "New Salvo" button or from the router table.
	In some cases, a blank salvo page is displayed resulting in a corrupt configuration in which the user is unable to edit salvos and the" New Salvo" button will no longer function.
	If this occurs, the user must reset the settings to factory, and then either reconfigure or restore from a backup before upgrading to the latest firmware release.



Cobalt Digital Inc. • 2506 Galen Drive • Champaign IL 61821 USA • (217) 344-1243 • www.cobaltdigital.com • support@cobaltdigital.com

Firmware Version	Description
Wave Router Series Firmware	Added Features
Release v1.6.3 08/02/2024 - 10/08/2024	 Destination Lock - You can now lock a specific destination from sources being routed to it. UI Scroll lock - The route grid UI will lock the destination and source headings when scrolling. This will allow the user to see the heading labels for the source or destination. Created a local UI route gridlock that only locks the routes on the device that initiated the lock. Clicking the lock icon for a specific route does not lock the route for other devices, only on the device that locked the route.
Wave Router Series Firmware	Added Features
Release v1.5.0 06/07/2024 - 08/02/2024	 This release includes a power and heat savings enhancement that turns off output drive 0 on all CDs. This eliminates the need to run extra cable driver hardware when not in use. The WAVE Router user interface now contains a lock button that locks the UI from invoking routes locally in the event of random clicks. Clicking the green Local Router Table Lock located in the upper-right corner of the Router Table page locks the user interface. Clicking the red Local Router Table Lock button allows the settings to be edited. Added functionality to verify serial and digital input rates. Hovering over the Destination or Source labels display the source number for a given source or destination. Since the source and destination names can be customized, hovering over a specific source or destination will display the actual source or destination number. A warning is now displayed when the router exceeds the normal operating temperature range. To disable the warning, click the Status tab in the Wave Router user interface and then add a check mark to the Crosspoint
	reporting high temperature field.
Wave Router Series Firmware Release v1.4.0 02/19/2024 - 06/07/2024	 Added Features Dynamic fan speed adjustments based on system temperature. The router configuration can be saved and restored via the UI. If there are several routers in a rack, you can enable a beacon to flash a LED on the router chassis to ID the unit. If the user does not disable it, the beacon will disable itself after 10 minutes. A text location description has been added to the UI to assist in identifying and locating the connected unit. The unit host name is now part of the logging information.
	 Non-responsive Salvo UI columns when column window was too small. Under certain conditions routes changes were not applied.

Cobalt Digital Inc. • 2506 Galen Drive • Champaign IL 61821 USA • (217) 344-1243 • www.cobaltdigital.com • support@cobaltdigital.com

Firmware Version	Description
Wave Router Series Firmware	Added Features
Release v1.3.0	 Support for RP-168 reference switching.
11/27/2023 - 02/19/2024	MADI input mode.
	 SW-P-08 Request supported commands on connection, which enables SetCrosspoint mode of operation.
	 SW-P-08 Get mnemonics support to allow source and destination name retrieval from the router.
	Bug Fix
	SW-P-08 Enhanced connectivity to the Companion software.
Wave Router Series Firmware	Added Features
Pre-Release v1.2.0	 Logging: The UI has a system Status tab showing status.
10/23/2023 - 11/25/2023	• We've added the change of status as a log entry into syslog.
	Bug Fix The system would drop video output due to resource sharing contingency. There are several hardware control endpoints that are shared between different threads. Due to the chain of hardware to control the endpoint, software synchronization was added to the whole chain itself rather than each component.
Wave Router Series Firmware	Added Features
Pre-Release v1.1.1	SW-P-08 protocol
10/12/2023 -1 2/23/2023	Temperature Status